



## Series B . Models Bxx-LC



### Meters for load cells

INDUSTRIAL SERIES . LARGE FORMAT METERS

*Large format industrial meters for load cells. Different formats available with 60 mm and 100 mm digit height, 4 and 6 digits, in red or green color. Sturdy metal housing, with full IP65 protection, designed for panel, wall or hanging mount. Versatile and configurable, provides excitation voltage to power up to 8 load cells. Fast access to alarm setpoints, 'tare' and 'auto-tare' functions, stability alarms, configurable operator menu, configurable brightness. Universal AC and DC power. Accepts up to 3 output and control options (relays, analog retransmission, Modbus RTU, transistor outputs, RS-485 ASCII, ...). Configuration from frontal keypad or remote keypad.*

# 1. Series B, models Bxx-LC

## Large format industrial meters for load cells

Large format meters for long distance reading, for industrial applications. Different formats available with 4 and 6 digits, with 60 mm and 100 mm digit height. Front keypad to access the configuration menu, and optional remote keypad.

For load cell signals, scalable reading from '999999' to '-199999' (or '9999' to '-1999' for 4 digit formats) and configurable decimal point. Provides excitation voltage configurable to +5 Vdc or +10 Vdc to power up to 8 standard 350 Ohm cells. 'Tare' function with configurable controls, and 'auto-tare' function for automatic tare correction when weight is removed from the cell. Three working modes with different acquisition speeds and noise rejection to 50 and 60 Hz.

Output and control options with 1, 2 and 3 relays, transistor outputs, controls for SSR relays, isolated analog outputs, communications in Modbus RTU, RS-485 ASCII and RS-232.

Independent alarms configurable as maximum or minimum, with activation at setpoint or when reading is stable, with 1 or 2 setpoints per alarm, hysteresis, independent activation and deactivation delays and configurable locked alarms (see section 1.13.9)

Sturdy metal housing with full IP65 protection. Internal connections by plug-in screw clamp terminals, and output through cable glands. Housing prepared for panel, wall and hanging mount.

- configurable '**Fast access**' to selected functions with key 'UP' (▲) (see section 1.13.13)
- tare accessible from frontal key or rear contact (see section 1.11)
- automatic 'auto-tare' function (see section 1.13.4)
- access to gross weight value and tare value (see section 1.9.4)
- function 'On power-up' for automatic activation of functions at start-up (see section 1.13.14)
- scale factor for easy modification of reading units (see section 1.13.5)
- 'stock units' function to count units (see section 1.13.6)
- access to the measured signal value (in mV), excitation current provided (in mA) and real excitation voltage (see section 1.13.15)

Multiple display filters, memory of maximum and minimum reading, password protection, 5 brightness levels.

### 1.1 How to use this manual


If this is the first time you are configuring a Series B large format meter, below are the steps to follow to install and configure the instrument. Read all the manual sections in

1. Identify the instrument format (see section 1.4)
2. Power and signal connections
  - open the instrument (see section 1.5)
  - connect the power (see section 1.7)
  - connect the signal (see section 1.10)
  - read recommendations to connect the 'sense' (see section 1.10.1) and for load cell ground connections (see section 1.10.2)
  - close the instrument (see section 1.5)
3. Initial setup (see section 1.13.2)
  - theoretical configuration of the cell (obtain the load cell data : sensitivity, load and excitation) and configure the instrument
  - apply the empirical configuration of the cell (apply the high and low 'field correction')
  - assign the 'system zero'
4. Advanced configuration (optional) (see section 1.13.7)
  - tare configuration, see sections 1.11 and 1.13.4
  - function 'stock units' (see section 1.13.6)
  - scale factor (see section 1.13.5)
  - acquisition modes (see section 1.9.1)

order to have a full and clear view of the characteristics of the instrument. Do not forget to read the installation precautions at section 1.21.

5. Configure the alarms (optional) (see section 1.13.8)
6. Display filters (optional) (see section 1.13.10)
7. Configure operator controls (optional)
  - configure the rear control (see section 1.13.11)
  - configure the front key 'LE' (◀) (see section 1.13.12)
  - configure the fast access (key 'UP' (▲)) (see section 1.13.13)
8. Configure other functions (optional)
  - configure the 'on power-up' function (see section 1.13.14)
  - configure the password and brightness level (see section 1.13.17)
9. If the instrument includes analog output (AO) or serial communications (RTU, S4, S2)
  - to include an option to an instrument see section 1.6
  - to configure an installed option, access the option configuration menu (see section 1.13.18)
  - see section 2 for information regarding the output and control options available
10. Install the instrument
  - mount on panel, wall or hanging (see section 1.20)
  - adjust the brightness level according to your environmental needs (see section 1.13.17)

## 1.2 How to order




## 1.3 Index

1. Series B, models Bxx-LC . . . . .	2	1.13.12 Front key 'LE' ( ◀ ) . . . . .	21
1.1 How to use this manual . . . . .	2	1.13.13 Fast access . . . . .	22
1.2 How to order . . . . .	3	1.13.14 'On power-up' function . . . . .	22
1.3 Index . . . . .	3	1.13.15 'Fast access' configuration menu . . . . .	23
1.4 Sizes and formats . . . . .	4	1.13.16 'On power-up' configuration. . . . .	23
1.4.1 Format B24. . . . .	4	1.13.17 Tools . . . . .	24
1.4.2 Format B44. . . . .	4	1.13.18 Access to the options configuration menu . . . . .	25
1.4.3 Format B26. . . . .	5	1.14 Full configuration menu. . . . .	26
1.4.4 Format B46. . . . .	5	1.15 Factory configuration . . . . .	28
1.5 To access the instrument. . . . .	6	1.16 Messages and errors . . . . .	29
1.6 Modular system . . . . .	6	1.17 Material included . . . . .	29
1.7 Power connections and protective earth . . . . .	7	1.18 Additional information . . . . .	29
1.8 Connections for remote keypad . . . . .	7	1.19 Practical cases . . . . .	30
1.9 Technical specifications. . . . .	8	1.19.1 Normal case . . . . .	30
1.9.1 Acquisition modes. . . . .	9	1.19.2 Load cell with external power . . . . .	30
1.9.2 Signal ranges. . . . .	9	1.19.3 Connections with a junction box . . . . .	30
1.9.3 Number and type of cells accepted . . . . .	9	1.19.4 Connections with 3 or 4 load cells . . . . .	31
1.9.4 Gross weight, net and tare . . . . .	9	1.19.5 Measuring mV at the laboratory . . . . .	31
1.10 Input signal connections . . . . .	10	1.20 Mounting. . . . .	32
1.10.1 Connecting the 'sense' . . . . .	10	1.21 Installation precautions . . . . .	33
1.10.2 Connecting the cell to the ground . . . . .	10	1.22 Warranty . . . . .	33
1.10.3 Real cases. . . . .	10	1.23 CE declaration of conformity . . . . .	33
1.11 'Tare' functions included . . . . .	11	2. Output and control modules . . . . .	34
1.12 Functions included . . . . .	11	2.1 Module R1. . . . .	34
1.13 Configuration . . . . .	13	2.2 Module T1 . . . . .	34
1.13.1 How to operate the menus . . . . .	13	2.3 Module SSR . . . . .	35
1.13.2 Initial set-up . . . . .	14	2.4 Module AO . . . . .	35
1.13.3 Initial setup menu . . . . .	15	2.5 Module RTU . . . . .	36
1.13.4 Function 'auto-tare' . . . . .	16	2.6 Module S4 . . . . .	36
1.13.5 Scale factor . . . . .	16	2.7 Module S2 . . . . .	37
1.13.6 Function 'stock' . . . . .	16	3. Other options and accessories . . . . .	38
1.13.7 Advanced configuration menu . . . . .	17	3.1 RKB - Remote keypad. . . . .	38
1.13.8 Alarms . . . . .	18	3.2 Red LED . . . . .	38
1.13.9 Alarm configuration . . . . .	19	3.3 Green LED . . . . .	38
1.13.10 Display filters . . . . .	20		
1.13.11 Rear controls . . . . .	21		

## 1.4 Sizes and formats

### 1.4.1 Format B24




Size A	340 mm
Size B	135 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm


Table 1 - Sizes B24

Cut-out G	322 mm (±1)
Cut-out F	117 mm (±1)

Table 2 - Panel cut-out B24



### 1.4.2 Format B44




Size A	542 mm
Size B	166 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm


Table 3 - Sizes B44

Cut-out G	524 mm (±1)
Cut-out F	148 mm (±1)

Table 4 - Panel cut-out B44



### 1.4.3 Format B26




Size A	436 mm
Size B	135 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm


Table 5 - Sizes B26

Cut-out G	418 mm (±1)
Cut-out F	117 mm (±1)

Table 6 - Panel cut-out B26



### 1.4.4 Format B46




Size A	740 mm
Size B	166 mm
Size C	3 mm
Size D	55 mm
Size E	25 mm

Table 7 - Sizes B46

Cut-out G	722 mm (±1)
Cut-out F	148 mm (±1)

Table 8 - Panel cut-out B46




## 1.5 To access the instrument

To open the housing, remove the screws from the back cover. With each screw there is a metal washer and a plastic washer. Once the screws are out, remove the back cover.

The figure below shows the instrument internal structure for a B26 format. It shows the location of the 3 slots for optional output and control modules, the power terminal and the input signal terminal.

To close the instrument, place the back cover, the screws, the metal washer and the plastic washer. The plastic washer is in contact with the back cover. Confirm that the screws are correctly turning inside the internal female screws.

To ensure a correct IP65 protection tighten the back cover screws with a strength between 30 and 40 Ncm, with the help of a dynamometer screwdriver.




## 1.6 Modular system

Large format meters from Series B are designed with an internal modular architecture. The output and control modules are independent and can be installed by accessing the internal circuits of the instrument, and connecting the module to the connection jumpers of the selected slot.

Each module is provided with a cable tie to fix the module to the tie base. The input signal modules defines the instrument function and are exchangeable, switching a temperature meter to an impulse counter only by replacing the input signal module.


See section 2. for information regarding the output and control options available




- To install an output and control module
- (1) insert the 'module pins' into the 'connection jumpers' in one of the free slots
  - (2) place the 'cable tie' into the 'tie base' and embrace the 'module' firmly, until it is fixed

## 1.7 Power connections and protective earth

1. Unscrew the screws from the back cover and remove the back cover (see section 1.5).
2. Pass the power cable through the power cable gland (see section 1.4).
3. Prepare the power cables so that the earth wire is 20 cm longer than the other cables (see Figure 1).




4. Connect the earth wire to the internal fixed screw 'PE' (see Figure 2) located at the inside of the back cover. The instrument internally connects the back cover metallic



structure with the front metallic structure through an internal green-yellow cable. (dotted cable at Figure 3).


5. Connect phase and neutral (in AC power) or positive and negative (in DC power) to the internal power terminal.
6. The connections label attached to the outside of the instrument has some free space left to write the color or local code for each cable.
7. To comply with security regulation 61010-1, add to the power line a protection fuse acting as a disconnection element, easily accessible to the operator and identified as a protection device.

Power 'H'	500 mA time-lag fuse
Power 'L'	1000 mA time-lag fuse



## 1.8 Connections for remote keypad

The 4 pin terminal located beside the input signal module allows to replicate a remote version of the front keypad. Connect 4 cables for front keys 'SQ' (■), 'UP' (▲) and 'LE' (◀) and for the common. Pass these cables through the 'remote keypad' cable gland (see section 1.4).



## 1.9 Technical specifications

<b>Digits</b>		signal terminals	plug-in screw terminals (pitch 3.81 mm)
number of digits	4 or 6 (see Table 9)	wires section	max. 0.5 mm <sup>2</sup>
digit	7 segments	<b>Power</b>	
view angle	120°	power 'H'	85 to 265 Vac and 120 to 370 Vdc iso- lated (isolation 2500 Vac)
color	red or green	power 'L'	11 to 36 Vdc isolated (isolation 1500 Vdc)
digit height	(see Table 9)	consumption	(see Table 9)
<b>Reading</b>		fuses	(see section 1.7)
max., min.	(see Table 9)	power terminals	plug-in screw terminals (pitch 5.08 mm)
decimal point	configurable	wire section	1 to 2.5 mm <sup>2</sup> (AWG17 to AWG14)
overrange / underrange	flash reading	<b>Configuration</b>	front keypad with 3 keys remote keypad (see section 1.8)
display refresh	(see Table 10)	<b>Output and control options</b>	relay output, analog retransmission, Modbus RTU, ... (see section 2)
<b>Load cells</b>		<b>Mechanical</b>	
type of cells	1 mV/V, 2 mV/V, 3 mV/V and others	IP protection	full IP65 housing
excitation voltage	configurable 5 Vdc or 10 Vdc	mounting	panel, wall , hanging (see section 1.20)
max. excitation current	140 mA	connections	cable gland outputs, PG9 (maximum 8 mm diameter)
Vexc. protection	against shortcircuit (see error at section 1.16)	housing material	texturized iron, black painted methacrylate front filter (see Table 9)
max. terminals voltage	30 Vdc	weight	(see section 1.4)
number of cells*	1 to 8 load cells (power 5 Vdc) 1 to 4 load cells (power 10 Vdc)	front sizes	(see section 1.4)
*(values calculated for standard 350 Ohms load cells. For cells with different impedance, the number is limited by the 140 mA available current)		panel cut-out depth	(see section 1.4)
<b>Measure</b>		<b>Temperature</b>	
signal ranges	(see section 1.9.2)	operation	from 0 to +50 °C
accuracy at 25 °C	(see section 1.9.2)	storage	from -20 to +70 °C
thermal stability	100 ppm/°	warm-up time	15 minutes
input impedance	20 MOhm		
acquisitions/second*	(see Table 10)		
*(and refresh for alarms, analog output and bus)			
display refresh	(see Table 10)		
step response	(see Table 10)		
	0% to 99% signal		

	Format B24	Format B44	Format B26	Format B46
Number of digits	4	4	6	6
Digit height	60 mm	100 mm	60 mm	100 mm
Reading distance	25 meters	50 meters	25 meters	50 meters
Slots for output and control options	2	2	3	3
Maximum reading	9999		999999	
Minimum reading	-1999		-199999	
Consumption (without options installed)	3 W	5.25 W	3.5 W	5.5 W
Consumption (with options installed)	5 W	6.75 W	5,5 W	7 W
Weight	2200 gr.	2500 gr.	3500 gr.	4500 gr.

Table 9 - Technical specifications associated to format



## 1.11 Technical specifications (cont.)

### 1.9.1 Acquisition modes

The instrument works by default with a fast acquisition mode of 16 acquisitions per second, with a noise rejection optimized for 50 and 60 Hz frequencies. Two additional faster acquisition modes are available, optimized for noise rejection to a single specific frequency of 50 Hz or 60 Hz.

To optimize the noise rejection only to 50 Hz and/or increase the acquisition speed to 50 acquisitions per second, configure

the 'Mode' ('ModE') parameter to '50.hZ' value. This selection increases the speed to 50 acquisitions per second and increases the noise rejection to 50 Hz, although it reduces the noise rejection to 60 Hz. Configure the parameter value to '60.hZ' to increase to 60 acquisitions per second and maximum rejection to 60 Hz noise, reducing the noise rejection for 50 Hz. To configure the mode see section 1.13.7.

	Acquisitions/sec.	Display refresh	Step response
<b>Mode standard</b>	16 acq./sec.	16 refresh/sec.	63 mSec.
<b>Mode 50 Hz</b>	50 acq./sec.	16 refresh/sec.	20 mSec.
<b>Mode 60 Hz</b>	60 acq./sec.	16 refresh/sec.	17 mSec.

Table 10 - Technical data for the configured acquisition mode

### 1.9.2 Signal ranges

The instrument works with 6 internal signal ranges and the active range is automatically selected when the instrument is started. The selection depends on the value of parameters 'Sensitivity' ('MV.V') and 'Excitation voltage' ('V.Exc') (see section 1.13.2).

*Example: with a sensitivity configuration of 2.0000 mV/V and a configured excitation voltage of 10 Vdc, the instrument selects the 20 mV input signal range, by calculating  $2 \text{ mV/V} \times 10 \text{ Vdc} = 20 \text{ mV}$ .*

The internal signal ranges available are shown below at Table 11.

Signal ranges	Accuracy	Max. input signal
0/100 mVdc	0.05% FS	30V
0/30 mVdc	0.05% FS	
0/20 mVdc	0.05% FS	
0/15 mVdc	0.05% FS	
0/10 mVdc	0.05% FS	
0/5 mVdc	0.05% FS	

Table 11 - Input signal ranges

### 1.9.3 Number and type of cells accepted

The instrument accepts connection for up to 8 standard 350 Ohms load cells. With a configured excitation voltage of 10 Vdc connect from 1 to 4 load cells. With a configured excitation voltage of 5 Vdc connect from 1 to 8 load cells. For load cells with different impedance, calculate the current consumption for each cell, and the total must not exceed the maximum current the instrument can provide.

In case of problems with the power or the signal provided by the load cells, the instrument provides three functions for troubleshooting purposes. These functions allow to access the signal input value (in mV), the excitation voltage value at the 'sense' terminals (in Vdc) and the current provided to the cells (in mA). The operator can use this values to identify the cause of the problem. See section 1.13.13 for more information on how to access this values in real time.

### 1.9.4 Gross weight, net and tare


The instrument shows the value for the net weight, and can be configured to switch reading to gross weight and the actual value of the tare. The relation between them is :

- Net weight = gross weight - tare

Operator can access these values by configuring the fast access menu (key 'UP (▲)') (see section 1.13.13).

## 1.10 Input signal connections

1. Unscrew the screws from the back cover and remove the back cover (see section 1.5).
2. Locate the input signal terminal (see section 1.4).
3. Pass the signal cable through the signal cable gland (see section 1.4).
4. Connect the input signal cables (see Figure 4).
5. The connections label attached to the outside of the instrument has some free space left to write the color or local code for each cable.



7. EK	'on / off' rear control (short circuit to 'Vexc-')
6. Vexc+	Excitation voltage +
5. Sense+	Excitation voltage sense +
4. Signal+	Positive signal
3. Signal-	Negative signal
2. Sense-	Excitation voltage sense -
1. Vexc-	Excitation voltage -

Figure 4 - Signal connections




Figure 5 - Example for connections with 1 load cell.

### 1.10.1 Connecting the 'sense'



The 'sense' terminals must be always connected. If you do not use the 'sense', shortcircuit with 'Vexc' terminals.

Measuring with load cells requires a stable and accurate excitation voltage. Connecting the 'sense+' and 'sense-' terminals to the load cell, provides the instrument with an accurate value of the excitation voltage received by the cell. Deviations and errors from the standard excitation value are automatically compensated by the instrument, increasing the accuracy. If you do not wish to use the 'sense', place a shortcircuit between terminals 'sense+' and 'Vexc+', and between terminals 'sense-' and 'Vexc-'.

For applications with multiple cells (2, 3, 4 cells or more) connect the 'sense' wires to the 'electrical middle point' of the power wires of all the cells (see section 1.19.4).

### 1.10.2 Connecting the cell to the ground

Measuring with load cells requires an electrically clean installation. When connecting the ground to the cell system, assure that :

- the cell connection to ground is performed in such a way that the current to ground DOES NOT flow through the cell.

### 1.10.3 Real cases

See section 1.19 for different examples on how to connect the load cell and configure the instrument.

## 1.11 'Tare' functions included

Activate the tare function to force the instrument to take the actual signal as a '0' weight. The tare function does not modify the internal calibration of the cell, and can be activated as many times as needed. The tare function is typically used to set a '0' reading when a fixed weight has been added to the load cell.

*Example : a truck enters a loading area and is placed on a weighing system. The instrument indicates that the weight of the truck is 2.500 Kg. A tare is applied to the instrument, and now the reading is 0 Kg. The truck enters the loading area and when it leaves, if is placed on the weighing system again. Now the reading is 1.550 Kg. This is the weight of the material loaded on the truck. When the truck leaves the weighing system the instrument reads -2.500 Kg. Activate a tare again to force a reading of 0 Kg or wait for a new truck.*

The instrument accepts different ways to activate the tare function:

- from the rear terminal, shortcircuit the 'EK' terminal against the 'Vexc-' terminal. Previously, configure the 'EK' terminal with the tare function (see section 1.13.11).
- from the front keypad, press the front key 'LE' (◀). Previously, configure the 'LE' (◀) key with the tare function (see section 1.13.12).
- automatically when the instrument starts. Previously, configure the 'on power-up' function with the tare function (see section 1.13.14).
- automatically with the 'auto-tare' function. The inherent mechanical characteristics of a load cell makes the 'zero weight' signal a non constant value. This can be detected by placing and removing the same weight from a load cell, several times. When the weight is removed, the reading is not always '0', but a random value close and around '0'. The 'auto-tare' function automates the activation of the 'tare' when the reading of the instrument is stable and close to '0' (see section 1.13.4).

To avoid accidental tares, the instrument provides the '**Max. Tare**' ('MAX.t') parameter. The activation of the 'tare' function, either manual or automatic, is not applied if the reading is higher than the value defined in this parameter (see section 1.13.7).

The actual tare value can be accessed from the front key 'UP' (▲) activating the 'Tare' function at the 'Key UP' menu (see section 1.13.15). A reset to the tare value can be applied also from this same menu.

## 1.12 Functions included

Included functions		Section
Function tare	yes	1.11
Auto-tare	automatic zero tare	1.13.4
Maximum tare	to prevent undesired tare activations	1.13.7
Scale factor	change the reading scale	1.13.5
Stock of units	counts units instead of weight	1.13.6
Modes	high rejection to 50 Hz and 60 Hz	1.9.1
Alarms	standard stability alarms double setpoint activation delays deactivation delays hysteresis inverted relay locked deactivation	1.13.8
Display filters	fixed digits recursive 'steps' left zeros	1.13.10
Rear controls	activate functions from rear terminal	1.13.11
Front key 'LE' (◀)	activate functions from key 'LE' (◀)	1.13.12
Fast access (key 'UP' (▲))	fast access to parameters from front key 'UP' (▲)	1.13.13
On power-up	activate functions at power up	1.13.14
Memory	maximum and minimum	1.13.13
Password	blocks access to configuration menu	1.13.17
Troubleshooting functions	values for input signal, excitation voltage and excitation current	1.13.13
Display brightness	5 levels	1.13.17

Table 12 - Functions included

Empty page

## 1.13 Configuration

### 1.13.1 How to operate the menus

The instrument has two menus accessible to the user :

'Configuration menu' (key 'SQ') (■)

'Fast access' menu (key 'UP') (▲)

#### Configuration menu

The 'configuration menu' modifies the configuration parameters to adapt the instrument to the application needs. To access the 'configuration menu' press for 1 second the 'SQ' (■) key. This access can be blocked by activating the 'Password' ('PASS') function. While operating the 'configuration menu', the alarm status is 'hold' to the status it had before accessing the menu, and the output and control modules remain in 'error' state. When leaving the 'configuration menu', the instrument applies a system reset, followed by a brief disconnection of the alarms and the output and control modules. Functionality is then recovered.

For a detailed explanation on the 'configuration menu' see the following sections, and for a full view of the 'configuration menu' see section 1.14.

#### 'Fast access' menu

The 'fast access' menu is an operator configurable menu, providing fast and direct access to the most usual functions of the instrument with a single key pad stroke. Press key 'UP' (▲) to access this menu.

See section 1.13.17 for a list of selectable functions for the 'fast access' menu in this instrument. The 'Password' ('PASS') function does not block access to this menu. Accessing and modifying parameters in the 'fast access' menu does not interfere with the normal functionality of the instrument, and it does not generate any system reset when validating the changes.

#### Operating with the front keypad inside the menus

**Key 'SQ' (■)** - press the 'SQ' (■) key for 1 second to access the 'configuration menu'. Inside the menu, the 'SQ' (■) key acts as an 'ENTER'. It enters into the menu option selected, and when entering a numerical value, it validates the number.

**Key 'UP' (▲)** - press the 'UP' (▲) key to access the 'fast access' menu. Inside the menu, the 'UP' (▲) key sequentially moves through the available parameters and menu entries. When entering a numerical value, it modifies the digit selected by increasing its value to 0, 1, 2, 3, 4, 5, 6, 7, 8, 9.

**Key 'LE' (◀)** - press the 'LE' (◀) key to activate the configured special functions associated to this key. Inside the menu, the 'LE' (▲) acts as an 'ESCAPE'. It leaves the selected menu level and eventually, by leaving all menu levels, it leaves from the configuration menu. Then changes are applied and the instrument is back to normal function. When entering a numerical value, it selects the active digit, and the value is then modified by key 'UP' (▲).

#### 'Rollback'

After 30 seconds without interaction from the operator, the instrument will rollback and leave the 'configuration menu' or the 'fast access' menu. All changes will be discarded.

#### Instruments with 4 and 6 digits

The configuration menus included in this document show values for a 6 digit instrument. In case of 4 digit instruments, note that maximum reading values should be 9999 instead of 999999 to 9999 and minimum reading values should be -1999 instead of -199999.




Figure 6 - Example of operation inside the 'configuration menu'

### 1.13.2 Initial set-up

Before starting to configure the instrument, identify the parameters of the load cell, at the manufacturers datasheet (see Table 13). If the parameters are not know, leave the instrument with the default values.

Load cell parameters	Default values
Sensitivity	2 mV/V
Nominal weight	1000 Kilos
Excitation voltage	10 Vdc

Table 13 - Parameters of the load cell

For an accurate measure, the instrument needs to correctly configure its parameters for the particular load cell connected. The configuration procedure has a first theoretical step and a second empirical step. The third and final step will set the 'system zero' of the instrument.

#### Theoretical configuration of the load cell

The theoretical parameters are configured at the 'Parameters of the cell' ('cELL') menu.

- at the 'Decimal point' ('dP') parameter, place the decimal point according to the resolution you want to see.
- at the 'Nominal weight' ('LoAd') parameter introduce the nominal weight of the load cell. The value is entered with the resolution configured in the parameter above.
- at the 'Sensitivity' ('MV.V') parameter, introduce the value of the cell sensitivity.
  - at the 'Excitation voltage' ('V.EXc') parameter, select 5 or 10Vdc. (The 'LAB' value enables the laboratory mode, for direct measure from a millivolt generator instead of a load cell (see section 1.19.5)).

Example : load cell with 1.95 mV/V sensitivity and a nominal value of 5 Kg and power 5 Vdc. To read in grams with a decimal point, configure the theoretical parameters as indicated below :

Decimal point : XXXXX.X  
 Sensitivity : 1.95 mV/V  
 Nominal weight : 5000.0  
 Excitation voltage : 5 Vdc

When the theoretical values are configured, leave the configuration menu. Apply a 'system zero'. Force a tare, and place different weights to check if the reading is correct. If it is not correct, apply the empirical configuration and again the 'system zero'.

#### Empirical configuration of the load cell

The second part of the load cell configuration is an empirical process of field correction. The instrument will detect and

correct the individual deviations of this particular load cell.

For the empirical configuration you will need access to two weights : a low weight, as small as possible (it can be the cell without weight) and a high weight as close as possible to the nominal weight of the cell.

In each case the meter will be informed of the real weight applied to the cell in order to correct and compensate for the measured deviations at the signal. Both corrections are need (high and low) for a correct configuration of the load cell.

- low weight correction : place the load cell without weight or with the smallest weight possible, and access the 'Low weight correction' ('F.Lo') menu. Press key SQ ('■'), introduce the value of the weight and press again SQ ('■'). The instrument will flash shortly and return to the menu entry 'Low weight correction' ('F.Lo').
- high weight correction : place the load cell with a weight closest to nominal and access the 'High weight correction' ('F.hI') menu. Press key SQ ('■'), introduce the value of the weight and press again SQ ('■'). The instrument will flash shortly and return to the menu entry 'High weight correction' ('F.hI').

Once both corrections are applied, leave the configuration menu. Force a tare, and place different weights to check that the reading is correct. As a last step, assign the 'system zero' if you want to access gross weight and net values.

#### Assign the 'system zero'

This is a necessary and important step for a correct measurement with a load cell.

- assign the 'system zero' : place the load cell without weight or with the weight that will be considered as 'zero' and access the 'System zero' ('S.ZEr') parameter. Press key SQ ('■'). The instrument will flash shortly and return to the menu entry 'System zero' ('S.ZEr').




The empirical configuration of the load cell recalculates and updates the theoretical sensitivity value ('Sensitivity mV/V' ('MV.V') parameter). Manual modifications of this parameter will modify the configuration of the cell. To prevent accidental modification consider the activation of the 'password' function (see section 1.13.17).



Once the load cell has been correctly configured, and the reading of the instrument is correct, it is not necessary to access again this part of the configuration menu. If you need to scale the reading to different units, use the 'Scale factor' ('SCL.F) parameters at the 'Advanced configuration' menu (see section 1.13.17).

### 1.13.3 Initial setup menu

Press 'SQ' (■) for 1 second to access the 'configuration menu'. For a description on how to operate inside the menus see section 1.13.1. For a full vision of the 'configuration menu' structure see section 1.14.



At the initial set up of the instrument, first configure the theoretical part of the load cell at the 'Load cell parameters' ('cELL') menu and later configure the empirical part of the load cell at the 'Field correction' ('F.cor') menu. See section 1.13.2 for additional information.

- at the 'Decimal point' ('dP') parameter, select the decimal point position. Move the decimal point with key 'LE' (◀). The position defined will be used for all reading parameters.

*Example : to read in 'Kg' with tenths of kilograms, place the decimal point at 'XXXXX.X' and the reading will be always be shown with 1 decimal.*

*Changing the position of the decimal point will only light a different decimal point led, but will not modify or re-scale the measure of the instrument.*

- at the 'Sensitivity mV/V' ('MVV') parameter, configure the value for the load cell sensitivity. Accepts any value between 0.0001 and 99.9999 mV/V. Default value is 2.0000 mV/V.
- at the 'Nominal weight' ('LoAd') parameter, configure the nominal weight of the load cell. accepts any value between 0 and 999999. The decimal point will be shown in the position configured at the 'Decimal point' ('dP') parameter. Default value is 1000.

*Example : for a 5 Kg cell, configure a value of 5000 to read in grams.*

- at the 'Excitation voltage' ('VExc') parameter, configure the voltage to power the load cell. Select '5 Vdc' or '10 Vdc'. Default value is 10 Vdc. Select 'LAB' for a millivolt meter mode in laboratory (see section 1.19.5).

The 'Field correction' ('F.cor') menu includes the functions for the empirical configuration of the load cell. See section 1.13.2 for additional information on each function.

- at the 'Low weight correction' ('F.Lo') parameter, introduce the real value of the actual weight at the cell. Use the lowest weight possible, close to 0. Press key SQ (■) to start the correction process.
- at the 'High weight correction' ('F.hI') introduce the real value of the actual weight at the cell. Use the lowest weight possible, close to nominal weight of the cell. Press key SQ (■) to start the correction process.

The 'System zero' ('S.ZEr') entry assigns the actual weight to the 'system zero' of the instrument. Values for 'gross weight' and 'tare' are relative to this weight. See section 1.13.2 for additional information.

### 1.13.4 Function 'auto-tare'

The 'auto-tare' function automatically activates the 'tare' when the weight is removed from the load cell. The 'auto-tare' configuration has three parameters :

- Activation value : the 'auto-tare' function activates when reading is lower than the defined value.
- Stability band: reading must be stable, and its fluctuation must be lower than the number of counts defined in this parameter.
- Stability time : reading must be within the stability band for the time defined in this parameter.

When these three parameters are met (the system is 'without weight' and the reading is 'stable') the 'auto-tare' function automatically activates the 'tare'.

*Example : weighing system with reading from 0.0 to 2500.0 Kg. When weight is removed from the system, there is always a variable remnant value : 2.2 Kg, 3.1 Kg, -0,7 Kg, ... This remnant value is associated to the specific imperfections of each load cell. Also this remnant value takes some time to stabilize, approximately 1 second. A manual tare can be applied each time the load cell is unloaded in order to correct this error. The 'auto-tare' function will correct it automatically without operator intervention, configuring the following parameters.*

- activation value = 5.0
- stability = 1.0
- stability time = 2 seconds

*When reading is lower than '5.0', the 'auto-tare' system activates, and it will analyze the stability of the signal. When reading does not change more than  $\pm 1.0$  counts for a time of 2 seconds, the tare will automatically activate.*

The 'auto-tare' function is affected by the '**Maximum tare**' ('MAX.t') parameter. The instrument will not accept the activation of the tare when reading is higher than the '**Maximum tare**' ('MAX.t') value.

### 1.13.5 Scale factor

The '**Scale factor**' ('SCL.F') configures a fixed multiplier to apply to the reading.

*Example: a weighing system is configured to read in Kg, but the system is going to be shipped to an area where measure must be in pounds. The relation between kilograms and pounds is: 1 Kg=2,20462 pounds. Within the scale factor, configure the multiplier to 220462 and the divider to 100000. The instrument is now configured to read in 'pounds'.*

### 1.13.6 Function 'stock'

The '**Stock units**' ('Stck') function is provided to count large quantities of small units, in situations such as stock inventory, reception of goods, etc. The operator must configure the number of 'units' assigned to a weight. The instrument will measure the weight but will show the number of 'units'.

To configure the '**Stock units**' function, weight a known number of units. Then introduce the number of units, either from the configuration menu ('Advanced configuration' \ 'Stock units') or from the fast access menu (key 'UP' (▲)).

*Example from the configuration menu : place 50 units on the load cell, and check that the instrument is weighing correctly. Enter the configuration menu, and at the 'Stock units' ('Stck') parameter, within the 'Advanced configuration', introduce '50' as the number of units. Save the value (key 'SQ' (■)) and leave the configuration menu (key 'LE' (◀) two times). The instrument restart and reads 50 units. Add more units and observe that the reading increases proportionally to the number of units.*


*Example from the front key 'UP' (▲) : configure the function 'Stock units' to be accessible from the front key 'UP' (▲) (fast access menu) (see section 1.13.13) and leave the configuration menu. Place 50 units on the load cell, and check that the instrument is weighing correctly. Access the parameter 'Stock units' through the front key 'UP' (▲), and configure the number of units actually on the load cell (50 units). Save the value (key 'SQ' (■)) and leave the fast access menu (key 'LE' (◀)). The instrument reads 50 units. Add more units and observe that the reading increases proportionally to the number of units*

In both cases, setting a value to the '**Stock units**' ('Stck') parameter assigns the value to the actual weight. The actual value of units ('**Stock units**' ('Stck') parameter) can be assigned to the actual weight by pressing front key 'LE' (◀) (see section 1.13.12) and/or activating the rear terminal 'EK' (see section 1.13.11).

Assign the value '0' to the '**Stock units**' ('Stck') parameter to disable this function and return to normal reading of weight.



### 1.13.7 Advanced configuration menu



At the 'Auto-tare' ('Aut.t') menu configure the activation value and stability values to control the automatic activation of the tare, when weight is removed from the cell. See section 1.13.4 for additional information.

- at the 'Activation value' ('SEt') parameter, configure the working limits for the 'auto-tare'. The 'auto-tare' only activates for lower values of reading. Accepts any value between 0 and 999999. Default value is 10.
- at the 'Stability band' ('bAnd') parameter, configure the number of counts allowed to consider a signal 'stable'. The 'auto-tare' only activates if the reading fluctuates within this band of counts. Accepts any value between 0 and 999999. Default value is 10.
- at the 'Stability time' ('tIME') parameter, configure the minimum time, in tenths of second, for the signal to be within the stability band to consider it 'stable'. Accepts any value between '0.0' and '99999.9'. Default value is '0.0'.

Value 0 at the stability band and/or 0.0 at the stability time, disable the 'auto-tare' function.

The tare is automatically activated when reading is lower than the activation value, and the fluctuation of the reading is lower than the counts defined at the 'stability band' for the time defined at the 'stability time'.

At the 'Maximum tare' ('MAX.t') parameter, configure the maximum value of reading to allow for a tare to be applied. See section 1.13.4 for additional information. Accepts any value between 0 and 999999. Default value is 999999.

At the 'Scale factor' ('ScL.F') parameter, configure the value for the multiplier and the divider. See section 1.13.5 for additional information. Accepts any value between 0 and 999999. Default value is 1.

At the 'Stock units' ('Stck') parameter, configure the number of units for the actual weight. See section 1.13.6 for additional information. Accepts any value between 0 and 999999. Default value is 0 (function disabled).

At the 'Mode' ('ModE') parameter, configure the acquisition mode. See section 1.9.1 for additional information. Default value is 'Standard' ('Std').

### 1.13.8 Alarms

The instrument manages 3 independent internal alarms, each one controlling the activation of an optional relay, transistor or SSR control output.

Optional modules (see section 2) are installed at the free slots inside the instrument (see section 1.6). B24 and B44 formats have 2 free slots for output and control modules, while B26 and B46 formats have 3 free slots for output and control modules (see section 1.4).

The instrument has 3 front leds that reflect the state of the 3 internal alarms. These leds are only for local help during installation, as they are not appropriate for long distance reading.

Each alarm controls the activation of the relay, transistor or control SSR installed on its associated slot, and the front led.

• **Configurable parameters**

Each alarm has several configuration parameters, starting with the usual setpoint, hysteresis and maximum (alarm active when reading is higher than setpoint) or minimum (alarm active when reading is lower than minimum) alarm types (see Figure 7).

• **Activation and deactivation delays**

Each alarm can configure independent activation and deactivation delays. These delays affect the alarm as a whole, and the delay will affect the front led and the associated relay.

• **Stability activation**

The stability activation delays the alarm activation until the reading is stable (see Figure 8).

*Application : the filling of a tank with liquid is controlled with a load cell. Upon reaching 5000 liters, the alarm 1 activates to stop the filling pump. After the pump has stopped, the liquid is still moving inside the tank, and this movement is reflected in weight and reading oscillations. Alarm 2 is configured as 'stability alarm' and activates when the liquid inside the tank is at rest. At this moment, the tank can be removed safely.*

• **Second setpoint**

Configuring a second setpoint creates 'windowed alarms'. The windowed alarm controls with a single relay output if the reading is inside or outside the values defined (see Figure 9).

• **Inverted relay**

Activate the 'inverted relay' function to invert the activation logic of the associated relay.

• **'Locked alarms'**

Activate the 'locked alarms' function to force the operator to interact with the instrument when an alarm has activated. Once activated, the alarm will remain locked at active state, even if the reading returns to a value below setpoint, until the operator manually unlocks the alarms by pressing the front key 'LE' (◀).




Figure 7 - Examples of alarms with 1 setpoint




Figure 8 - Example of alarm with stability





Figure 9 - Example of alarm with double setpoint

### 1.13.9 Alarm configuration



Alarms 1, 2 and 3 are configured from menu 'ALr1', 'ALr2' or 'ALr3'. See section 1.13.8 for additional information.

- at the 'Active' ('Act') parameter select 'on'
- at the 'Type of alarm' ('TypeE') parameter, select 'MAX' for maximum alarm (activates when reading is higher than setpoint), or 'Min' for minimum alarm (activates when reading is lower than setpoint).
- at the 'Setpoint' ('SEt') parameter, configure the alarm activation point. Value accessible through the 'fast access' menu (see section 1.13.13).
- at the 'Hysteresis' ('hYST') parameter, select the hysteresis value. Hysteresis applies to the alarm deactivation. Alarm deactivates once the reading is beyond the setpoint plus the hysteresis value. Hysteresis prevents relay switching in case of signal fluctuations close to the setpoint value.
- at the 'Activation delay' ('dEL.0') parameter, configure the delay to apply before the alarm is activated. Delay starts to count once the setpoint is reached. Value from 0.0 to 99.9 seconds.
- at the 'Deactivation delay' ('dEL.1') parameter, configure the delay to apply before the alarm is deactivated. Delay starts to count once the setpoint is reached plus the hysteresis value. Value from 0.0 to 99.9 seconds.
- at the 'Stability' ('StbL') parameter, configure the conditions to detect stability at the signal and activate the alarm. Value '0' at 'stability band' or at 'stability time' deactivate the stability control of the alarm.
  - at the 'Stability band' ('bAnd') parameter, configure the number of counts that the reading can change and still be considered stable. Values from 0 to 999999. Default is 10.
  - at the 'Stability time' ('TIME') parameter, configure the time, in tenths of second, that the reading must be within the 'stability band' to be considered stable. Values from 0.0 to 99999.9. Default is 0.0.
- to work with 'windowed alarms' configure 'Setpoint 2' ('SEt2') to 'on' and configure the value for the second setpoint. The second setpoint must always be higher than the first setpoint.
- at the 'Inverted relay' ('r.Inv') parameter, configure 'on' to invert the activation of the relay. Relay is inactive when alarm is active, and relay is active when alarm is inactive.
- at the 'Locked alarm' ('A.Lck') parameter, configure 'on' to block the automatic alarm deactivation. Alarm deactivation must be performed manually, by pressing the front key 'LE' (◀) (see section 1.13.12) or rear control (see section 1.13.11).


### 1.13.10 Display filters

The instrument provides several functions to act upon the reading in order to increase stability, reduce noise and adapt to particular needs. These functions are grouped under the ‘Display’ (‘dISP’) menu and are explained below :

- the ‘Fixed digits’ (‘FIX.d’) function allows to fix each digit to a fixed value. Typically, one or more right digits are fixed to ‘0’. Fix digits starting from the right. Value ‘-’ indicates that the digit is not fixed.
- the ‘Average filter’ (‘AVr’) applies a recursive filter upon the reading values, in order to reduce oscillations due to noisy signals. Configure the filter strength between ‘0’ and ‘100’. The filter is stronger with higher values. Increasing the strength of the filter slows the reading. Value ‘0’ disables the filter.
- the ‘Steps’ (‘StEP’) function configures the reading to be done in steps of 1, 2, 5, 10, 20 or 50 counts.

*Example: configure a step of 20 and the reading will change in steps of 20 counts (‘1420’, ‘1440’, ‘1460’, ...).*

- the ‘Left zero’ (‘LZEr’) function lights all zeros to the left.
- the ‘Memory of maximum’ (‘MAX’) displays the maximum reading stored on memory. To reset this memory, select the ‘rSt’ input. The value can be accessed through the ‘fast access’ menu at front key ‘UP’ (▲) (see section 1.13.13).
- the ‘Memory of minimum’ (‘MIn’) displays the minimum reading stored on memory. To reset this memory, select the ‘rSt’ input. The value can be accessed through the ‘fast access’ menu at front key ‘UP’ (▲) (see section 1.13.13).




### 1.13.11 Rear controls

The instrument provides a digital 'on/off' input at the rear terminals, referenced as 'EK' (see section 1.10). Assign functions to this terminal and activate these functions with a short circuit between terminal 'EK' and terminal 'Vexc-'. Functions available are explained below :

- the 'Tare' ('tArE') function applies a tare.
- the 'Alarm unlock' ('A.LcK') function unlocks all alarms that are locked due to the 'Locked alarms' function (see section 1.13.8).
- the 'Stock units' ('Stck') function assigns the actual weight to the number of units defined at the 'stock units' parameter (see section 1.13.6).

In case of multiple functions enabled, the activation is performed sequentially in the same order as the configuration menu (first is the tare, then the alarm unlock, etc).




### 1.13.12 Front key 'LE' ( ◀ )

The front key 'LE' ( ◀ ) can be configured to activate a set of functions. Functions available are explained below :

- the 'Tare' ('tArE') function applies a tare.
- the 'Alarm unlock' ('A.LcK') function unlocks all alarms that are locked due to the 'Locked alarms' function (see section 1.13.8).
- the 'Stock units' ('Stck') function assigns the actual weight to the number of units defined at the 'stock units' parameter (see section 1.13.6).

In case of multiple functions enabled, the activation is performed sequentially in the same order as the configuration menu (first is the tare, then the alarm unlock, etc).



### 1.13.13 Fast access

The *'fast access'* is an operator configurable menu. When configured, the operator can access the most usual functions with a single press of the front key 'UP' (▲). Functions available are listed below :

- access to alarm setpoints from the front key 'UP' (▲) allows to read and modify the actual setpoint values
- access to the 'stock units' parameter from the front key 'UP' (▲) allows to read and modify the actual 'stock value' parameter. See section 1.13.6 for additional information about the 'stock units' function.
- values for 'gross weight' and 'tare' are accessible from the front key 'UP' (▲) (see section 1.9.4). To reset the tare value visualize the value and press key 'UP' (▲). When message 'rSt' appears, press key 'SQ' (■). The instrument returns to visualize the 'tare' value. Press key 'LE' (◀) to leave the menu.
- functions 'signal mV', 'exc. voltage' and 'exc. current' give access to values for the input signal measured in mV, the excitation voltage measured in Vdc between terminals 'sense+' and 'sense-', and the excitation current measured in mA provided from the instrument to the load cell

These three functions act as an integrated voltmeter and ammeter, to be used for troubleshooting purposes, as they give information on the real signals received and provided to the load cell.

- access to maximum and minimum memories from the front key 'UP' (▲) allows to visualize the values. To reset the maximum or minimum value, visualize the value, and press key 'UP' (▲). When message 'rSt' appears, press key 'SQ' (■). The instrument returns to visualize the actual memory

value. Press key 'LE' (◀) to leave the menu

The *'fast access'* menu is not affected by the password function, allowing to have a locked access to the general configuration menu, while still some functions are accessible to the operator through the *'fast access'* menu.

#### • **Super fast access**

If only one function is configured at the *'fast access'* menu, pressing the front key 'UP' (▲) will shortly read the name of the function and then automatically show into the value.

### 1.13.14 'On power-up' function

The **'On power-up'** (**'on.Pu'**) menu allows to define a series of functions to activate when the instrument restarts after a power loss.


Functions available are a delay on the activation of measure and control functions, and a tare function.

These functions will activate only after a restart due to power-loss, they will not apply after a restart due to changes in configuration.

Delay the measure and control functions gives time to slow system elements to start completely before the instrument begins to acquire signal and control the outputs.

While on delay mode, the instrument shows all decimal points lightened and flashing, all alarms are deactivated, and there is no signal acquisition or communications control. When the delay time is over, the instrument starts its normal functioning.


### 1.13.15 'Fast access' configuration menu



At the 'Key UP ('fast access') ('K.uP') menu configure which functions and parameters will be accessible through the 'fast access' menu. Select 'on' to activate each function. See section 1.13.13 for additional information.

- the 'Setpoint 1' ('ALr1') function allows to visualize and modify the setpoint for alarm 1.
- the 'Setpoint 2' ('ALr2') function allows to visualize and modify the setpoint for alarm 2.
- the 'Setpoint 3' ('ALr3') function allows to visualize and modify the setpoint for alarm 3.
- the 'Stock units' ('Stck') function allows to visualize and modify the quantity of units defined at the 'stock units' parameter (see section 1.13.6).
- the 'Gross weight' ('Gros') function allows to visualize the gross weight.
- the 'Tare value' ('tArE') function allows to visualize the actual tare value.
- the 'Signal mV' ('c.MV') function allows to visualize the actual value of the input signal, without scaling. Value is offered in mV.
- the 'Exc. voltage' ('c.EXc') function allows to visualize the actual value of the excitation voltage, measured between terminals 'sense+' and 'sense-'. Value is offered in Vdc.
- the 'Exc. current' ('c.MA') function allows to visualize the actual value of the current provided by the instrument to the load cell. Value is offered in mA.
- the 'Memory of maximum' ('MAX') or 'Memory of minimum' ('MI n') allows to visualize and/or reset the actual value of the maximum and minimum memory.

### 1.13.16 'On power-up' configuration



The 'On power-up' ('on.Pu') menu assigns functions to apply when the instrument restarts after a power loss. See section 1.13.14 for additional information.

- at the 'Delay' ('dLAY') parameter configure the time the instrument waits before starting normal operation. Value between 0 and 200 seconds.
- at the 'tare' ('tArE') parameter configure to 'on' to activate a tare every time the instrument restarts after a power loss.

### 1.13.17 Tools


The **'Tools'** (**'tool'**) menu groups functions with a variety of uses.

- at the **'Password'** (**'PASS'**) function define a numerical code to block access to the 'configuration menu'. Activate the password to prevent access to the instrument configuration by non authorized personnel. To activate the **'Password'** function select **'on'** and enter the code.

The numerical code is asked when accessing the 'configuration menu' (key 'SQ' (■)). Functions configured to be accessible through the 'fast access' menu are not **'Password'** blocked.


- at the **'Factory configuration'** (**'Fact'**) select **'yes'** to activate the default factory configuration (see section 1.15 for a list of default parameters). The cell configuration parameters (**'Initial conf.'** (**'Init'**) menu) are not affected by this reset if the **'Reset 'initial conf.'** (**'F.Inl'**) parameter is **'off'**.

- at the **'Reset 'initial conf.'** (**'F.Inl'**) parameter select **'on'** to include the cell configuration parameters when activating the default factory configuration.

 The factory reset applied to the 'initial configuration' parameters affects the cell configuration parameters. For a correct reading, a new cell configuration must be applied, as indicated in section 1.13.2.

- the **'Version'** (**'VER'**) parameter informs about the firmware version loaded on the instrument.

- At the **'Brightness'** (**'LIGh'**) parameter select the intensity of the display brightness. Five levels available. With this function the instrument brightness can be adapted to match the brightness of nearby instruments.






### 1.13.18 Access to the options configuration menu

The output and control options are optional modules that can be installed at the instrument. Formats B24 and B44 have 2 free slots for output and control options, while formats B26 and B46 have 3 free slots (*see section 1.4*).

Several of these optional modules have their own configuration menu embedded.


The '**Opt.1**', '**Opt.2**' and '**Opt.3**' menu entries give access to the configuration menu of the option installed.



See section 2 for a list of available output and control modules




### 1.14 Full configuration menu

Press 'SQ' (■) for 1 second to access the 'configuration menu'.





## 1.15 Factory configuration



Initial configuration ('Init')	
Load cell parameters ('cELL')	
Decimal point ('dP')	without (XXXXXX)
Sensitivity mV/C ('MV.V')	2.0000
Nominal weight('LoAd')	200000
Excitation voltage ('V.Exc')	10Vdc ('10')
Advanced configuration ('AdvC')	
Auto-tare ('Aut.t')	
Activation value('SEt')	10
Stability band ('bAnd')	0 (disabled)
Stability time ('tIME')	0.0 (disabled)
Maximum tare ('MAX.t')	999999
Scale factor ('ScL.F')	
Multiplier ('MuLt')	1
Divider('dIV')	1
Stock units ('Stck')	0 (disabled)
Mode ('MODE')	standard ('Std')
Alarms 1,2 and 3 ('ALr.1', 'ALr.2', 'ALr.3')	
Active ('Act')	off (disabled)
Type ('tYPE')	maximum ('MAX')
Setpoint ('SEt')	1000
Hysteresis ('hYSt')	0 counts
Activation delay ('dEL.0')	0.0 seconds
Deactivation delay ('dEL.1')	0.0 seconds
Stability ('StbL')	
Stability band ('bAnd')	10 counts
Stability time ('tIME')	0.0 (disabled)
Setpoint 2 ('SEt.2')	off (disabled)
Inverted relay ('r.InV')	off
Locked alarms ('A.LcK')	off
Display ('dISP')	
Fixed digits ('FIX.d')	no fixed digits ('-----')
Average filter('AVr')	0 (disabled)
Steps ('StEP')	1
Left zeros ('LZEr')	off
Memory of maximum ('MAX')	-199999
Memory of minimum ('MIn')	999999
Rear controls ('r.ctr')	all 'off'
Key LE ('K.LE')	
Tare	on
Alarm unlock	off
Stock units	off
Key UP ('K.uP')	all 'off'
On power-up	
Delay	0
Tare	off
Tools	
Password ('PASS')	off
Reset 'initial conf.'('F.Ini')	off
Brightness ('LIGH')	3

## 1.16 Messages and errors

Error messages related to the local instrument are shown on display, in flash mode. Examples given are for instrument with 6 digit formats.

<b>Messages and errors</b>	
'd.udr' 'd.ovr'	display underrange ('d.udr')/overrange ('d.ovr'). The display is already reading the minimum/maximum value possible (-199999/999999).
'Err.0'	incorrect scaling (vertical slope)
'Err.1'	incorrect password.
'Err.2'	when accessing an 'oPt.X' menu entry, there is no recognize module installed.
'Err.6'	in 'stock units' mode, weight value is 0 and can not be assigned to a quantity of units.
'Err.8'	over current at the excitation voltage.
'----'	requested reading is not accessible (reading of units with the 'stock units' mode disabled).

Table 14 - Messages and error codes

## 1.17 Material included

The shipment includes :

- 1 instrument Bxx-LC
- 1 user's manual

If the instrument mounts output and control options (see section 2), the shipment also includes:

- 1 user's manual for output and control options

## 1.18 Additional information

User's manual

- [www.fema.es/docs/4625\\_Bxx-LC\\_manual\\_en.pdf](http://www.fema.es/docs/4625_Bxx-LC_manual_en.pdf)

Datasheets

- [www.fema.es/docs/4630\\_B24-LC\\_datasheet\\_en.pdf](http://www.fema.es/docs/4630_B24-LC_datasheet_en.pdf)
- [www.fema.es/docs/4631\\_B26-LC\\_datasheet\\_en.pdf](http://www.fema.es/docs/4631_B26-LC_datasheet_en.pdf)
- [www.fema.es/docs/4632\\_B44-LC\\_datasheet\\_en.pdf](http://www.fema.es/docs/4632_B44-LC_datasheet_en.pdf)
- [www.fema.es/docs/4633\\_B46-LC\\_datasheet\\_en.pdf](http://www.fema.es/docs/4633_B46-LC_datasheet_en.pdf)

Declaration CE

- see section 1.23

Warranty

- [www.fema.es/docs/4153\\_Warranty1\\_en.pdf](http://www.fema.es/docs/4153_Warranty1_en.pdf)

Web

- [www.fema.es/Series\\_B](http://www.fema.es/Series_B)

## 1.19 Practical cases

### 1.19.1 Normal case

Case for 1 load cell, powered from the instrument, with power 10Vdc, nominal weight 100 Kg and 2 mV/V sensibility.

- Connect the load cell to the instrument (see section 1.10).
- Configure the 'theoretical configuration of the load cell' (see section 1.13.2).
- Apply the 'empirical configuration of the load cell' (see section 1.13.2).
- Configure the 'system zero' (see section 1.13.2).

Depending on the specifications of your load cell, you may need to apply a 'tare' each time that the weight is removed from the load cell. See at section 1.11 the different options available to activate the 'tare' function.

### 1.19.2 Load cell with external power

Case for 1 load cell, with external power.

- Connect the load cell normally, and **do not** connect 'Vexc+'. Connect 'Sense+' and 'Sense-' to the load cell. 'Vexc-' must be connected to 'Sense-'. See Figure 10.
- Configure the 'theoretical configuration of the load cell' (see section 1.13.2). The value assigned to Vexc does not affect the measure.
- Apply the 'empirical configuration of the load cell' (see section 1.13.2).
- Configure the 'system zero' (see section 1.13.2).

Depending on the specifications of your load cell, you may need to apply a 'tare' each time that the weight is removed from the load cell. See at section 1.11 the different options available to activate the 'tare' function.




Figure 10 - Connections for external power

### 1.19.3 Connections with a junction box



A 'junction box' for load cells has internal electronics that can modify the 'signal/weight' relation provided to the instrument. Check the manufacturer documentation of the junction box.

Case for 4 load cells connected to a 'junction box'. It is assumed that the 'junction box' is used as a simple 'connections box'. All 4 load cells are the same type of load cell, with nominal weight of 100 Kg and 2 mV/V sensibility.

- Connect the 4 load cells to the 'junction box'. Connect the instrument to the 'junction box' using 4 or 6 wires, as indicated in the 'junction box' documentation. If 4 wires 'junction box' is used, see section 1.10.1 to connect the 'sense' wires not used ('sense' wires must connected).
- Configure the 'theoretical configuration of the load cell' (see section 1.13.2). Take note that the sensitivity of the system remains the same (2 mV/V) and the nominal weight of the system is the addition of the nominal weight of each cell (4 x 100 Kg = 400 Kg)
- Apply the 'empirical configuration of the load cell' (see section 1.13.2).
- Configure the 'system zero' (see section 1.13.2).

Depending on the specifications of your load cell, you may need to apply a 'tare' each time that the weight is removed from the load cell. See at section 1.11 the different options available to activate the 'tare' function.




Figure 11 - Example for 4 load cells connection through a 'junction box' or 'connections box'.

## 1.19 Practical cases (cont.)

### 1.19.4 Connections with 3 or 4 load cells

Using 3 load cells is the optimal way to distribute the weight on a plane, although it is common to work with 4 load cells, in applications with tanks, hoppers and similar.

When working with multiple load cells, the optimal connection is the one that makes the wires of the cell converge in the same central area, so that all the cells are at the same 'electrical distance' from the meter.

Use the same type load cell (for example, load cells with nominal load of 100 Kg and sensitivity of 2 mV/V) and connect the wires to the central area as indicated below. Configure the instrument as indicates in this manual, assuming that :

- the sensitivity of the system remains the same (2 mV/V)
- the nominal weight of the system is the addition of the nominal weight of each cell (3 x 100 Kg = 300 Kg for 3 cells or 4 x 100 Kg = 400 Kg for 4 cells)
- the 'sense' wires are carried to the central zone together with the Vexc wires, but are not propagated to each individual cell. If you do not want to use the 'sense' wires, see section 1.10.1.




Figure 12 - Connection example with 3 load cells.




Figure 13 - Connection example with 4 load cells.

### 1.19.5 Measuring mV at the laboratory

If you wish to configure the instrument to measure a millivolt generated signal at the laboratory, there is a special configuration to apply. Different from the load cell, the millivolt generator is not a differential system, and does not need excitation voltage.

- Connect the instrument to the millivolt meter (see Figure 14). Add 2 resistances of 10 KOhm to connect the 'Vexc' terminals to the common of the signal generator.
- Inside the 'configuration menu', select the 'Vexc' parameter to 'Lab' (see section 1.13.2). This value deactivates the ratiometric measurement and activates the direct millivolt measurement.
- At the additional parameters at the 'theoretical configuration of the load cell' (see section 1.13.2) assign the desired reading and the mV/V parameter. Note that values of 1 mV/V, 2 mV/V and 3 mV/V will activate a full scale range of 10 mV, 20 mV and 30 mV respectively.
- **Do not** apply the 'empirical configuration of the load cell' (see section 1.13.2). Applying this characterization to the signal generator will only generate a reduction in the measurement accuracy.
- Configure the 'system zero' (see section 1.13.2). This step is needed for a correct mV measurement. Generate 0mV and 'assign the system zero'.



To reduce leak currents that can affect the laboratory measurement:

1. if the millivolt generator is powered from the mains network, use an isolator transformer to power the generator
2. if the instrument is powered from the mains network, use a separate isolator transformer to power the instrument




Figure 14 - Connections for 'laboratory' mode

## 1.20 Mounting

The instrument fixations are designed to allow panel mount, wall mount, or hanging mount. For each type of mounting,

- Panel mount. Apply the cut-out to the panel as seen on section 1.4. Remove the side fixations. Introduce the instrument into the panel cut-out. Mount the side fixations as shown (see Figure 15). Slightly loosen the fixation screw of one side and press the instrument against the panel. Tighten the fixation screw so it presses the panel and maintains the fixation. Repeat with the opposite side fixation.




Figure 15 - Panel mount

see the position of the fixations at the images below.

- Wall mount. Mount the side fixations against the wall, as shown (see Figure 17). Each fixation has 2 holes with 4,5 mm diameter and a separation between hole centers of 30 mm. Once the side fixations are secured against the wall, place the instrument and press the fixation screws slightly. Tilt the instrument to the desired viewing angle and firmly screw the fixation screws.




Figure 17 - Wall mount

- Hanging mount. Mount the side fixations as shown (see Figure 16). Each fixation has 2 holes with 4,5 mm diameter and a separation between hole centers of 30 mm. Instrument can be hanged using cable, threaded rod, ....




Figure 16 - Hanging mount



## 1.21 Installation precautions



Risk of electrical shock. Instrument terminals can be connected to dangerous voltage.



Instrument conforms to CE rules and regulations.

This instrument has been designed and verified conforming to the 61010-1 CE security regulation, for industrial applications. Installation of this instrument must be performed by qualified personnel only. This manual contains the appropriate information for the installation. Using the instrument in ways not specified by the manufacturer may lead to a reduction of the specified protection level. Disconnect the instrument from power before starting any maintenance and / or installation action. The instrument does not have a general switch and will start operation as soon as power is connected. The instrument does not have protection fuse, the fuse must be added during installation.

An appropriate ventilation of the instrument must be assured. Do not expose the instrument to excess of humidity. Maintain clean by using a humid rag and do NOT use abrasive products such as alcohols, solvents, etc.

General recommendations for electrical installations apply, and for proper functionality we recommend : if possible, install the instrument far from electrical noise or magnetic field generators such as power relays, electrical motors, speed variators, ... If possible, do not install along the same conduits power cables (power, motor controllers, electrovalves, ...) together with signal and/or control cables.

Before proceeding to the power connection, verify that the voltage level available matches the power levels indicated in the label on the instrument.

In case of fire, disconnect the instrument from the power line, fire alarm according to local rules, disconnect the air conditioning, attack fire with carbonic snow, never with water.

## 1.22 Warranty

This instrument is warranted against all manufacturing defects for a period of 36 MONTHS from the shipment date. This warranty does not apply in case of misuse, accident or manipulation by non-authorized personnel. In case of malfunction get in contact with your local provider to arrange for repair. Within the warranty period and after examination by the manufacturer, the unit will be repaired or substituted when found to be defective. The scope of this warranty is limited to the repair cost of the instrument, not being the manufacturer eligible for responsibility on additional damages or costs.

## 1.23 CE declaration of conformity

Manufacturer FEMA ELECTRÓNICA, S.A.  
 Altimira 14 - Pol. Ind. Santiga  
 E08210 - Barberà del Vallès  
 BARCELONA - SPAIN  
 www.fema.es - info@fema.es

Products B24-LC, B44-LC, B26-LC, B46-LC

The manufacturer declares that the instruments indicated comply with the directives and rules indicated below.

Electromagnetic compatibility directive 2014/30/EU

Low voltage directive 2014/65/EU

Directive ROHS 2011/65/EU

Directive WEEE 2012/19/EU

### Security rules EN-61010-1:2010

Instrument Fixed, Permanently connected  
 Pollution degree 1 and 2 (without condensation)  
 Isolation Basic + Protective union

### Electromagnetic compatibility rules EN-61326-1:2013

EM environment Industrial

### Immunity levels

EN-61000-4-2	By contact ±4 KV	Criteria B
	By air ±8 KV	Criteria B
EN-61000-4-3		Criteria A
EN-61000-4-4	On AC power lines: ±2 KV	Criteria B
	On DC power lines: ±2 KV	Criteria B
	On signal lines : ±1 KV	Criteria B
EN-61000-4-5	Between AC power lines ±1 KV	Criteria B
	Between AC power lines and earth ±2 KV	Criteria B
	Between DC power lines ±0.5 KV	Criteria B
	Between DC power lines and earth ±2 KV	Criteria B
	Between signal lines and earth ±1 KV	Criteria B
EN-61000-4-6		Criteria A
EN-61000-4-8	30 A/m at 50/60 Hz	Criteria A
EN-61000-4-11	0 % 1 cycle	Criteria A
	40 % 10 cycles	Criteria A
	70 % 25 cycles	Criteria B
	0 % 250 cycles	Criteria B

### Emission levels

CISPR 11 Instrument Class A, Group 1 Criteria A

Barberà del Vallès October 2020  
 Xavier Juncà - Product Manager

Declarations available:

CE - [www.fema.es/docs/5647\\_CE-Declaration\\_B\\_en.pdf](http://www.fema.es/docs/5647_CE-Declaration_B_en.pdf)

UK CA - [www.fema.es/docs/5653\\_UKCA-Declaration\\_B\\_en.pdf](http://www.fema.es/docs/5653_UKCA-Declaration_B_en.pdf)



According to directive 2012/19/EU, electronic equipment must be recycled in a selective and controlled way at the end of its useful life.

# 2. Output and control modules

## 2.1 Module R1

The R1 module provides 1 relay output to install in large format industrial meters from Series B. Formats B26 and B46 accept up to 3 relays, and formats B24 and B44 accept up to 2 relays.

Configuration is performed from the front keypad of the instrument, by setting the alarm parameters. Check the alarm menu parameters at the instrument user's manual for full information.

Modules R1 can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 18 - Module 'R1' and internal schematic

Type of relay	3 contacts (Com, NO, NC)
Max. current	3 A (resistive load)
Voltage	250 Vac continuous
Isolation	3500 Veff
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Common
B	NO (Normally Open)
C	NC (Normally Closed)

Figure 19 - Connections for 'R1' relay output module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

## 2.2 Module T1

The T1 module provides 1 transistor output to install in large format industrial meters from Series B. Formats B26 and B46 accept up to 3 transistor outputs, and formats B24 and B44 accept up to 2 transistor outputs.

Configuration is performed from the front keypad of the instrument, by setting the alarm parameters. Check the alarm menu parameters at the instrument user's manual for full information.

Modules T1 can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 20 - Module 'T1' and internal schematic

Type of output	transistor
Max. voltage	35 Vdc
Max. current	50 mA
Isolation	3500 Veff, optoisolated
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Emitter
B	Collector
C	Not connected

Figure 21 - Connections for 'T1' transistor output module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

## 2.3 Module SSR

The SSR module provides 1 output for SSR relay control, to install in large format industrial meters from Series B. Formats B26 and B46 accept up to 3 SSR control outputs, and formats B24 and B44 accept up to 2 SSR control outputs.

Configuration is performed from the front keypad of the instrument, by setting the alarm parameters. Check the alarm menu parameters at the instrument user's manual for full information.

Modules SSR can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.






Figure 22 - Module 'SSR' and internal schematic

Type of output	for SSR relay control
Output voltage	+15 Vdc
Max. current	45 mA
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Not connected
B	Collector (-)
C	+15 Vdc (+)

Figure 23 - Connections for 'SSR' control module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

## 2.4 Module AO

The AO module provides 1 analog output, configurable for 4/20 mA or 0/10 Vdc signal, to install in large format industrial meters from Series B. Formats B26 and B46 accept up to 3 analog outputs, and formats B24 and B44 accept up to 2 analog outputs.

Output signal is fully scalable, both with positive and negative slopes, and is proportional to the reading. The mA output can be configured for active loops (the instrument provides the power to the mA loop) or passive loops (the loop power is external to the instrument).

Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

AO modules can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 24 - Module 'AO'

Signal output	4/20mA, 0/10Vdc (active and passive)
Accuracy	0.1% FS
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Excitation voltage
B	Signal in mA or Vdc
C	Common
Jumper M	Jumper closed for mA output
Jumper V	Jumper closed for Vdc output

Figure 25 - Connections for 'AO' analog output module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

## 2.5 Module RTU

The RTU module provides an isolated Modbus RTU communications port, to install in large format industrial meters from Series B.

The RTU module implements function '4' ('Read Input Registers') of the Modbus RTU protocol, to access the instrument registers (reading value, alarm status, memory of maximum and minimum, ...).

Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

Modules RTU can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 26 - Communications module 'RTU'

Protocol	Modbus RTU
Bus	RS-485, up to 57.6 Kbps
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Bus signal A
B	Bus signal B
G	GND

Figure 27 - Connections for Modbus 'RTU' communications module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

## 2.6 Module S4

The S4 module provides an isolated RS-485 ASCII communications port, to install in large format industrial meters from Series B.

The S4 module implements a MASTER / SLAVE protocol, with up to 31 addressable slaves. In SLAVE mode allows access to reading values, alarm status, memory of maximum and minimum, ...

Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

Modules S4 can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 28 - Communications module 'S4'

Protocol	ASCII
Bus	RS-485, up to 57.6 Kbps
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	Bus signal A
B	Bus signal B
G	GND

Figure 29 - Connections for RS-485 'S4' communications module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

## 2.7 Module S2

The S2 module provides an isolated RS-232 ASCII communications port, to install in large format industrial meters from Series B.

The S2 module implements a MASTER / SLAVE protocol, with up to 31 addressable slaves, with 'daisy-chain' connection. In SLAVE mode allows access to reading values, alarm status, memory of maximum and minimum, ...

Configuration is performed from the front keypad of the instrument, by accessing the menu entries 'Opt.1', 'Opt.2' or 'Opt.3', according to the slot where the module is installed.

Modules S2 can be provided factory installed into a Series B instrument, or standalone for delayed installation. No soldering or special configuration is required. See section 1.6 on how to install output and control modules.





Figure 30 - Communications module Module 'S2'

Protocol	ASCII
Bus	RS-232, up to 57.6 Kbps
Isolation	1000 Vdc
Terminal	plug-in screw clamp, pitch 5.08 mm
Installation allowed at	slot 1, slot 2, slot 3



A	'Daisy chain' Tx data transmission
B	'Daisy chain' Rx data reception
C	Tx data transmission
D	Rx data reception
E	GND

Figure 31 - Connections for RS-232 'S2' communications module

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

For more information:  
[http://fema.es/docs/4326\\_SERIES-B\\_OPTIONS\\_manual\\_en.pdf](http://fema.es/docs/4326_SERIES-B_OPTIONS_manual_en.pdf)

# 3. Other options and accessories

## 3.1 RKB - Remote keypad

Remote keypad for large format industrial meters from Series B. Replicates a remote version of the front keypad, close to the operator.

(\*Cable not provided).



## 3.2 Red LED

Red LED



## 3.3 Green LED

Green LED



Empty page



**DIGITAL PANEL METERS**  
 Section Industrial



**SIGNAL CONVERTERS**  
 Section Industrial



**LARGE DISPLAYS**  
 Section Industrial



**PANEL METERS . LOW COST**  
 Section OEM



**CONVERTERS . ISOLATORS**  
 Section OEM



**LARGE DISPLAYS**  
 Section Special



**SPECIAL INSTRUMENTS**  
 Section Special



**DATA ACQUISITION**  
 Section Industrial



**'CUSTOMIZED' INSTRUMENTS**